

Datasheet

Austenitic stainless steel

Osprey® N-60

Osprey® N-60 is a nitrogen-strengthened stainless steel with good wear and galling resistance, typically used for automotive, oil/gas, chemical processing and general-purpose applications.

UNS
S21800

Powder designed for
Metal Injection Moulding (MIM)



Product description

Osprey® N-60 is a nitrogen-strengthened stainless steel with good wear and galling resistance. The alloy is typically used for automotive, oil/gas, chemical processing and general-purpose applications. Osprey® N-60 is an alloy of the same type as Nitronic® 60*.

This metal powder is manufactured by Inert Gas Atomization (IGA), producing a powder with a spherical morphology which provides good flow characteristics and high packing density. In addition, the powder has a low oxygen content and low impurity levels, resulting in a metallurgically clean product with enhanced mechanical performance.

*Nitronic is a trademark owned by AK Steel Corporation.

Chemical composition (nominal), %

Last updated: Jul 17, 2023 9:57 AM CET

Fe	Bal.
C	0.1
Cr	16.0-18.0
Ni	8.0-9.0
Mo	
Si	3.5-4.5
Mn	7.0-9.0
S	
P	
Other	N 0.08-0.18

Powder characteristics and morphology

Powder for Metal Injection Moulding (MIM)

Osprey® MIM powder has a spherical morphology, resulting in high packing density. This enables the manufacture of feedstocks with high powder loading, which not only minimizes binder costs but also reduces part shrinkage during debinding and sintering. Spherical powder also has excellent flow characteristics, resulting in reduced tool wear and consistent mould filling.

Osprey® MIM powder's low oxygen content allows better control of carbon and consistency during sintering. Low oxygen levels, together with high packing density, also facilitate faster sintering.

Particle size distribution

Powder for Metal Injection Moulding (MIM)

Osprey® metal powder for Metal Injection Moulding (MIM) is available in a wide range of particle size distributions, from under 5 µm up to 38 µm. The table shows our standard particle size distributions for MIM powders.

Size (µm)	D10 (µm)	D50 (µm)	D90 (µm)
≤ 38	5.5	13.0	31.0
≤ 32	5.0	12.0	29.0
80% ≤ 22	4.5	11.5	27.0
90% ≤ 22	4.0	10.5	22.0
90% ≤ 16	3.5	8.0	16.0

*Particle size measurements performed using a Malvern laser particle size analyzer, typical D10, D50 and D90 provided.

Tailor-made particle size distributions are available on request. Contact us to discuss your specific requirements.

Testing

All Osprey® metal powders are supplied with a certificate of analysis containing information on the chemical composition and particle size distribution. Information on other powder characteristics is available upon request.

Packaging

A wide range of packaging options is available, from 5kgs plastic bottles to 250kg metal drums.

5 kg (11 lbs) Plastic bottles

6 kg (13 lbs) Plastic bottles

10 kg (22 lbs) Plastic bottles

20 kg (44 lbs) Metal cans

100 kg (220 lbs) Steel drums

150 kg (330 lbs) Steel drums

250 kg (551 lbs) Steel drums

All packaging materials are suitable for air, sea and road freight.

Contact us for more information and to discuss your packaging requirements.